digitech

# Solar Emergency Handcrank Radio

with LED Light, SOS Siren & 3.5mm Earphone Jacks



Model: AR1944

**Instruction Manual** 

# **PACKAGE CONTENTS:**

- AM/FM Radio
- Micro USB Charging Cable
- Wrist Strap
- Instruction Manual

# **RADIO OPERATION:**

#### **TUNING**

Rotate the tuning knob to select your frequency. The tuning indicator will light up when a strong signal is found.

#### VOL +/VOL-

Rotate the VOL+/VOL- knob to adjust the volume.

### LIGHT ON/OFF/SOS


Adjust the LIGHT ON/OFF/SOS button to turn the LIGHT ON & OFF. Switch to SOS to emit an emergency alarm.

## OFF/FM/AM


Select OFF/FM/AM with the BAND selector to turn off your radio. Select your desired band. Extend the antenna to get a better signal.

#### LED READING LAMP

Pull the solar panel up at a 90° angle to activate the reading light.








Hand Crank 3 x AA Battery Slot

# **POWER YOUR RADIO:**

Before you power your radio, make sure to read the SAFETY INSTRUCTIONS.

#### **SOLAR POWER**

- Position the radio in direct sunlight to ensure that the solar panel receives adequate exposure.
- Do not leave your radio in a hot area for extended periods, such as a hot car.
- Turn off the radio when charging.






#### DC IN 5V CHARGING


- To charge the radio, insert the supplied USB cable into a USB power source.
   Insert the Micro USB connector located under the rubber seal.
- The charging indicator will flash red as the battery charges. It takes 2.5 hours for the internal 18650 2500mAh LI-ION battery to be fully charged.
- When fully charged, the battery will provide 11-12 hours of radio play (depending on sound level), 41 hours of flash light use, or 48 hours of reading lamp use.

IMPORTANT: Ensure the battery setting is switched to LI-ION mode before charging. This setting is required to ensure proper functionality and safe charging of the internal 18650 2500mAh LI-ION battery.

#### HAND CRANK


- Unfold the radio's handle from the back and rotate it in either direction.
- Turn the hand crank for 5 minutes to activate the internal battery for initial use.
- Five minutes of winding results in 15-20 minutes of radio play (at maximum volume), 2 hours of reading lamp use, and 1.4 hours of flashlight use.






#### 3 x AA BATTERY

- This radio can also be powered by three AA batteries (not included).
- Remove the battery compartment cover and insert three AA batteries.
- Replace the battery compartment cover and switch the radio battery switch to the 'AA' position to turn the radio on.
- If you want to store your radio for extended periods, please be sure to remove the batteries to avoid corrosion damage.



#### **EXTERNAL DEVICE CHARGING**

- Select the "LI-ION" position on the side panel, as shown in the diagram below.
- Insert the USB cable into the 'USB out' port to connect your devices to charge.
- You can charge USB devices with three AA batteries. You can also use the dynamo function and crank at 130-150 RPM.



#### Note:

- This feature is only for charging USB devices during emergency situations. Do not use it regularly as a power bank.
- The supplied charging cable is only for charging the radio from a USB power source or charging device that accepts Micro-USB.

# **SPECIFICATION:**

Product Name	AM/FM Dynamo Hand Crank Radio With SOS/Torch/Reading lamp/Phone Charger/Solar Panel	
Color	Yellow	
Material	ABS Plastic	
AM	520-1620KHz	
FM	87-108MHz	
Power Source/ Charging options	Solar Panel/Hand Crank/2500MAh rechargeable battery/backup 3 x AA Battery (not included)	
Features	Solar Panel/Built-in speakers/SOS/High-sensitivity Antenna/Earphone jack/USB out 5V/DC in 5V/Torch 1W/ Reading Lamp 2W/Hand Crank/Hand strap	
Dimensions	15.5 x 4.2 x 9.4cm	
Weight	364g	

# **SAFETY INSTRUCTIONS:**

- Dropping this radio can cause injury or damage. The unit will not resist strong impact or contact with corrosive liquids.
- This radio is not waterproof, only water-resistant to an extent. Keep the unit dry, as moisture and liquids can cause damage.
- Wind the crank for 3-5 minutes before using it to activate and keep the internal battery healthy.

Distributed by: Electus Distribution Pty Ltd 46 Eastern Creek Dr, Eastern Creek NSW 2766 Australia Ph 1300 738 555 Int'l +61 2 8832 3200 Fax 1300 738 500

www.electusdistribution.com.au

Made in China