


# PORTABLE FAN



- 1.POWER OFF KEY
- 2.CHARGING LIGHT
- 3.LEVEL 1 LIGHT
- 4.LEVEL 2 LIGHT
- 5.LEVEL 3 LIGHT

- 6.POWER ON/SWITCH KEY
- 7.USB PORT FOR CHARGING
- 8.TORCH
- 9.BATTERY COVER

## Insert Batteries

- a.Take off the batteries compartment cover
- b.Insert the batteries and make sure the polarity is correct
- c.Replace the cover



## Using the fan

- a.Press the POWER ON key once, the fan will run, the level 1 light will be on,
- b.Press the POWER ON key once more, the fan will run level 2, the level 2 light will be on,  
Press POWER ON key once more, the fan will run level 3, and level 3 light will be on.
- c.Press POWER ON key once more, the torch will be on, and the fan will stop
- d.Press POWER ON key once more, the torch will be off
- e.POWER OFF key, during the operation, press POWER OFF key will stop the operation

## Power

Battery model: 18650, 3.7v

Charging power: input voltage: 5v, input current: 0.5-1A

Fan Power: MAX 4.5W

size:20x19cm