

CONCORD



5W Solar Panel

suitable for wireless cameras

Instruction Manual

QC3911

Box Contents

Solar Panel	×1
Mounting Base	×1
Screws	×3
Wall Anchors	×3
Quick Start Guide	×1



Solar Panel



Mounting Base



Screws



Wall Anchors

Specifications


Product Dimensions:168x184x14mm
Cable length:3m
Operating voltage:5V DC
Operating temperature:-20.5°C to 48.5°C(-5°F to 120°F)

Installation Instructions


Place Solar Panel in an area with consistent sunlight throughout the year.It only needs a few hours of direct sunlight each day to keep your camera powered.

The amount of energy that the solar panel produces is affected by weather conditions,seasonal changes, geographic location,etc.


- 1 Fix the base to your mounting location using the included screws.If the installation surface is soft or unstable,first use a $\phi 6.0$ drill bit to drill a hole in the wall,then insert the anchor nail into the hole,and fix the base with screws.




- 2 Screw the solar panel into the mounting base.Make sure the universal joint faces upward.




- 3 If you need to adjust the solar panel left or right, loosen the locking screw cap, turn the sleeve rod, and tighten the locking screw cap when the panel is in position.



- 4 Solar panel's angle can be adjusted up and down up to 90°.



Tip: After the installation is complete, please check that all locking mechanisms are tightly secured, and then connect the solar panel to the camera's Type-C charging port.




The solar panel's cable length: 2.2m (7.22 feet)

How to position your solar panel

- 1 Find the area that gets the most direct sunlight throughout the day
- 2 The recommended tit angle between the panel and the horizontal ground is 30°.
- 3 Point it south if in the northern hemisphere and north if in the southern hemisphere.

Important

- 1 Wipe the face of the solar panel with a soft ,damp cloth regularly to clear any dust or debris.
- 2 Be sure to update the firmware version of the camera to the latest version.



Completed Installation

Warranty Information

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by: Electus Distribution
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766
Ph. 1300 738 555