



TAA020

Ensuite Shower Tent



INSTRUCTION MANUAL

USAGE INSTRUCTIONS

Set Up

1



2



3



4



5



Set Up

1. After removing the shelter from its carrying case and laying it on a flat surface, spread the 4 legs of the shelter out to the side,
2. Take the center pole and pull straight out to lift the top of the tent up and then push down on the 4 inner poles until they lock into place.
3. Extend each of the leg poles upward until they lock into place. (For take down simply press the button on each of them and lower down).
4. To secure shelter to the ground, slide the provided stakes in the bottom corner loops and drive them into the ground to secure. For added security, use the 4 guy lines provided at each corner and attach them to additional stakes, tightening as needed.
5. Drape rain cover over top of tent and snap each plastic clip located at the corners of the cover into the corresponding clip on the leg pole. Adjust strap accordingly.

Take Down

1. Remove the rain cover by unsnapping the clips at each corner and fold the rain cover.
2. Remove any objects from inside the shelter and take out the stakes and guylines from the ground.
3. With each leg pole, press the button located in the middle and lower the poles until they collapse down.
4. Push down on the lower bars of the hub to collapse the shelter.
5. Fold the 4 legs and roll shelter up to fit in its carrying case.

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555