



TLE862

Square Camping Light with Power Bank



Instruction Manual

WARNINGS & SAFETY INFORMATION

Please read through these operating instructions carefully and thoroughly. These instructions form part of the product and contain important start-up and handling information. Always observe all the safety instructions. Please keep these instructions in a safe place, and pass them on, if necessary, to third parties.

Warning

- Do not install in a humid environment, under direct sunlight or near gas outlets.
- When the battery runs flat, ensure you charge the product back up to maximise the lifetime of the unit.
- Please do not attempt to open the product as this will void warranty.
- Charge unit only using a suitable 5V USB outlet.
- This product has an inbuilt battery, it is strongly advised not to disassemble, puncture or place into fire. If there are signs of swelling, do not continue to use the product.
- Once the LED Light source reaches its end of life it can not be replaced.
- Please keep this product out of reach of children and do not use this product in high temperature environments.

FUNCTIONS

Power Button

Short press once to turn ON 100%

2nd Press - 75%, 3rd Press - 50%

4th Press - 25%, 5th Press - OFF

Long press to adjust dimming function.

Lighting Button

When the light is off, double press to begin flashing RED and BLUE light, press again to turn OFF.



SPECIFICATIONS

Input Voltage:	DC 5V
Electric current:	1 A
Lumen:	600
Power:	5-7W
Charge Time:	8hrs
Run Time:	16hrs
Battery:	10,000mAh
Material:	ABS
Light source:	2835
Product size:	130 x 130 x 54mm

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by: Electus Distribution
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766
Ph. 1300 738 555