



**YS2860**

# **Shower Tent**



**INSTRUCTION MANUAL**

## CONTENTS

Box Contents.....	3
Before First Use.....	3
Installation.....	4
Pack Up Instructions.....	5
Cleaning, Care, Storage & Maintenance .....	5
Warranty Information.....	6

## BOX CONTENTS



1x Shower Tent

2x Brackets

4x Pegs

## BEFORE FIRST USE

Prior to using your product, please read all the safety and operating instructions thoroughly. Please ensure you follow the steps below before using the product. We recommend you keep the original packaging for storing the product when not in use.

Please pay close attention to the section entitled Important Safety and General Instructions. Find a safe and convenient place to keep this instruction manual for future reference.

Unpack the product but keep all packaging materials until you have made sure your new product is undamaged and in good working order. Ensure you have all accessories listed in this manual. Plastic wrapping can be a suffocation hazard for babies and children so ensure all packaging materials are out of their reach.

**WARNING: The manufacturer is not responsible for any potential injury from misuse**

## INSTALLATION



1. Insert bolt heads into the slots in the aluminium extrusion.



2. Use the supplied "L-Bracket and mounting hardware to attach to the vehicle.



3. Unzip weather resistant cover and release the mechanical fasteners, allowing the fabric to be released.



4. Move the arms outward and lock in place.



5. Unfold the fabric and allow it to hang, adjust the webbing straps at the top to achieve the required height from the ground.



6. Peg out the four corners and tension the webbing straps as required.

## **PACK UP INSTRUCTIONS**

1. Remove the pegs with a claw hammer or peg puller. Do not remove pegs from the ground by pulling on shower tent base as this may cause damage.
2. Reverse steps from 4 to 1.
3. Ensure the shower tent is dry before packing into storage bag.

## **CLEANING, CARE, STORAGE & MAINTENANCE**

- Clean with a damp cloth.
- Store away in a cool dry place away from dirt and debris.

## WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555