


Smart Tag





WARNING – KEEP BUTTON BATTERIES OUT OF REACH OF CHILDREN


- If swallowed a lithium button battery may lead to serious or fatal injury in as little as 2 hours, due to chemical burns and potential perforation of the oesophagus
- All button batteries must be kept away from children regardless if they are new or used.
- If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poisons Information Centre on 13 11 26 (Australia) or 0800 764 766 (New Zealand) for fast, expert advice.
- If your child is having difficulty breathing contact 000 (Australia) or 111 (New Zealand).
- Dispose of used button batteries immediately and safely out of the reach of children. A battery can still be dangerous even when it can no longer operate the device.
- As soon as you have finished using a button battery, put sticky tape around both sides of it. This will make it harder for children to swallow the button battery and avoid the risk of the battery catching fire.
- Immediately dispose of button batteries immediately out of reach of children, or recycle using a child resistant container and take used cells to your local battery collection centre.

Specifications	
Model	RSH-Tag08 (LA4222)
Size	41.2x41.2x13 mm
Weight	16.5g
Battery	CR2450 (Non Replaceable)
Current	≤5uA(Standby) / ≤10mA(Max)
Wireless	BLE 5.2
Wireless range	≥40m (Line-of-sight)
Buzzer	Built-in ≥75db (in 10cm)
Temperature range	- 5°C - 45°C
Humidity range	≤95% (Non-condensing)

Quick instructions

1. Turn on the device and pair

- Press the function button once to turn it on. It should beep indicating it is powered on



2. Pair the device

- Open the Find My app.
- Hold the device close to your iPhone, iPad, tap the Items tab, tap + and then Add Other Item.
- Tap Connect.
- Type a name for your device.
- Tap Agree to acknowledge that this item will be linked to your Apple ID.
- Tap Finish.

3. Enable Lost Mode

- Open the Find My app, tap the Items tab, then tap your item.
- Under Lost Mode, tap Enable.
- Follow the instructions, tap Continue, and enter contact information.
- Customise the lost message, then tap Activate.

4. Remove the device

- Open the Find My app, tap the Items tab, then tap your item.
- Tap Remove Item and then tap Remove to complete the operation.

Note: You can link the device in ten minutes by opening the Find My app after removing it from the app. The device will exit pairing mode if it is not repaired in ten minutes. and at this moment, pairing the device and app is not possible. The gadget will beep if you need to link it; if so, push the button for three seconds. The gadget can now be paired with the app since it has entered the pairing state.

1. Locate your item

The Find My app can assist you in finding your misplaced item even if it is not in close proximity by utilising the Find My network, which comprises hundreds of millions of iPhone, iPad, and Mac devices globally. Your missing device's position is securely sent to iCloud by nearby devices, and you may view its whereabouts using the Find My app. Encrypted and anonymous to ensure the privacy of all parties involved.

2. Play Sound

- Open the Find My app, tap the Items tab, then select your device.
- Click Play Sound, and the device will beep, so you can find th

Instructions for device button

1. Pairing state

Long press the button for 3 seconds, the device will beep and the device will enter the pairing state.

2. Re-pairing the device

After removing the device from the app, it will not shut down and will be in pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state. If you want to pair a device at this time, you need to press and hold the button for 3 seconds. The device will beep and enter the pairing state. At this time, the device enters the pairing state and can be paired with the app again.

3. Factory Reset

Delete the device from the "Find My" application then quickly press the function button four times, then press and hold it for the fifth time until you hear a ringing tone. Release the button to restore factory settings.

4. Serial number lookup

1. Locate the button on the front of the Smart Tag.
2. Press the button once.

FAQ:

1. When can the device be located?

When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.

2.How is the device designed to discourage unwanted tracking?

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

- if you have an iPhone, iPad, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
- if you don't have an iOS device or a smart phone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specially to discourage people from trying to track you without your knowledge.

3.How is my privacy protected?

Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple knows the location of your device or the identity of the device that helps find it.

4. Expected battery lifespan:

The battery cannot be replaced. It has a lifespan of up to 3 years.

5. What is the Find My network? And how does it work?

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple, can view its location.

Important tips:

When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following actions are recommended:

- Change the phone's network, such as switching between WiFi and mobile network;
- Factory Reset for the device.
- Re-pairing with Find My app.

Safety Statement

Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.

The application of low power frequency electric machinery shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations.

The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machinery and equipment for legal communications or industrial and scientific applications.

Warranty

Our product is guaranteed to be free from quality and manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim. Should you not be able to provide proof of purchase with a receipt or bank statement, identification showing name, address and signature may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Credit line

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Compatibility statement

To use the Apple Find My app to locate this item, the latest version of IOS, iPadOS, or macOS is recommended.

Made in China

How to connect products ?




- 1 Long press the function button for 3 seconds, and the device will enter the pairing state.

- 2 Open FindMy app



FindMy




3 Add items


4 Add other supported items




5 Search product smart tag



6 Connection naming




7 Select emoticons




8 Agree to register



9 Complete registration



10 FindMy function page



Note: If you need to return and refund, please be sure to remove the device before returning it to avoid your privacy disclosure

Can't connect? Troubleshooting

1. In FindMy, please ensure you are selecting "Add Other Items" as there is no "Add AirTag" option.
2. Factory reset: press the function button four times, then press and hold it for a fifth time until the device emits a beep sound
3. Confirm that you are connected to the internet on your mobile device.
4. Restart your mobile device.