



## PRODUCT DATA SHEET

NORGLASS LABORATORIES PTY.LTD.

A.B.N. 92 001 807 245

P.O. Box 312, Neutral Bay. NSW 2089 Australia

59 Moxon Road, Punchbowl NSW

Ph: 61 2 9708 2200 Fax: 61 2 9796 3069

Email: norglass@bigpond.net.au

www.norglass.com.au

## STAYBOND EPOXY GLUE

**DESCRIPTION:** A non staining gap filling, 2 pack epoxy adhesive of exceptionally high strength and

cohesive value.

**USES:** As a waterproof, structural glue for boatbuilding and laminating work. Also used for

bonding fibreglass, metals, concrete, ceramics and glass to themselves or to dissimilar

materials.

## PROPERTIES (At 20°C)

COLOUR: Translucent cream

**TOXICITY:** See Precautions

FINISH: Non staining, light amber

**COVERAGE:** 1 mixed litre = 1000cu.cm. (1 mixed litre will cover 1m<sup>2</sup> at 1mm thick)

**DRYING TIME:** Workable after 24 hours. Full cure 7 days

**RECOATING:** N/A

POT LIFE: 30 minutes at 50% relative humidity (subject to mass). Storage life minimum of 5 years if

correctly sealed. NOTE: The hardener deteriorates quickly if not sealed properly.

**MIXING RATIO:** 1:1 by volume.

**THINNING:** NOT BE THINNED UNDER ANY CIRCUMSTANCES.

WEIGHT/LITRE: 0.95kg when mixed

**VOLUME SOLIDS:** Exceeds 99%

FLASH POINT: Non volatile

CLEAN UP: NORGLASS EPOXY THINNER

**U.N. NUMBER**: FREE



**PREPARATION** TIMBER:

Remove all forms of grease, oil, water or other contaminants.

Sand timber at 45degrees to the grain. Vacuum off all sanding dust from the grain.

This is essential for adhesion.

Wipe over the surface to be glued with Acetone or Methylated spirits on a clean cloth and

allow to dry.

Oily timbers such as teak should be wiped down with NORGLASS ACETONE to remove

surface oils, and be coated with STAYBOND EPOXY GLUE within 20 minutes.

If left too long, more oil will rise to the surface of the timber reducing the overall adhesion.

OTHER SURFACES: All other substrates should be sandblasted or thoroughly solvent cleaned

to ensure positive bonding.

APPLICATION: Scoop out an equal volume of STAYBOND Base and Hardener (using separate spatulas)

onto a mixing board and blend together thoroughly.

Blending or mixing should be done with a stick or spatula **not contaminated with either** 

base or hardener. Mark each appropriately.

Mix together until a creamy paste is achieved and no sign of unblended material remains.

(streakiness)

Note: Under no circumstances can the mixing ratio of 1:1 by volume be altered or other extenders be added to the mix. Adding excess Hardener will make the mix rubbery not

In cold weather prewarm both components by standing the cans in hot water for

15 minutes before mixing.

TRANSPORTATION: Non Dangerous Goods.

> 7.6Kg 3.8Kg 1.9Kg 950a 470a 200a (40L) (8L) (4L) (2L) (1L) (500ml) (250ml)

PRECAUTIONS:

Do not attempt to glue when the surface temperature is below 10degreesC or when the

temperature is likely to fall to that point during the first 12 hours of glueing.

Replace lids to both cans tightly when not is use.

Do not glue to charred or blackened timbers caused by burning off or high speed

sanding. These areas must be planed or re-dressed before glueing.

Provide adequate ventilation during use. Avoid contact with skin and eyes and do not

smoke or eat without thorough washing.

Do not leave the lid off the hardener as this product deteriorates rapidly when left

exposed to air and/or humid conditions, rendering the product ineffective.

**FIRST AID:** 

If poisoning occurs call a doctor or Poisons Information Centre (Aust) on 13 11 26 or

(NZ) 0800 764 766 and have label information ready.

If swallowed DO NOT induce vomiting. Give large quantities of water or milk. In case of eye contact, flush immediately with plenty of water for at least 15 minutes and consult a doctor. Remove contact lenses if present and east to do and continue rinsing. In case of contact with skin, remove contaminated clothing and wash skin thoroughly. If breathing

difficulty arises remove to fresh air. Apply artificial respiration if not breathing.

SPECIAL **INSTRUCTIONS:**  Cramping times should be at least 48 hours at 20degreesC.

Note: Do not starve joints of glue by over cramping (especially on open grained

timbers). Remove all exuded glue before setting begins.

Complies with British Standards 1204 parts 1 & 2 for water and boil proof criteria.

Any advice, recommendation, information, assistance or service provided by NORGLASS in relation to goods manufactured or supplied by it or their use and application is given in good faith and is believed by NORGLASS to be appropriate and reliable. However, any advice, recommendation, information, assistance or service provided by NORGLASS is given without liability or responsibility.